


User Manual

RAM 4



plum
MOBILE

CONTENT


BASIC INFORMATION	3
Phone Instruction	3
Interface Icons	4
Insert SIM card	5
Charging the battery	5
Power on/Off your phone	5
FUNCTION MENU.....	6
PHONEBOOK.....	6
MESSAGING.....	6
Write messag	6
Inbox	6
CALL CENTER	7
Call history	7
Call settings	7
SETTINGS	8
Dual SIM settings	8
Phone settings	8
Network settings	9
Security settings	9
Connectivity	10
AUDIO PLAYER.....	11
MULTIMEDIA	11
Camera	11
Image viewer	11
Video recorder	12
Video player	12
Sound recorder	12
FM radio	13
PROFILES.....	13
FILE MANAGER.....	14
Phone	14
ORGANIZER	14
Calendar	14
Flashlight	15
EXTRAS.....	15
Calculator	15
EBook reader	15
SERVICES.....	15
1. Internet service:	15
SAFETY PRECAUTION	16
OTHER WARNINGS.....	17

Specifications

Basic information

Phone Instruction





Interface Icons

Icon	Description
	Signal Strength
	Missed Call
	New message
	Power indicator
	Alarm

Insert SIM card

The SIM card contains your private information such as your phone number and Phonebook.

·The SIM card slot is located inside the phone, for the installation, open the back cover, take out the battery and find the SIM card slot.

Put the SIM card metal face down, gently insert to the card slot, and fix it. You must turn the phone off before you replace the SIM card.

·Please operate SIM card carefully, friction or bending may damage the SIM card.

Charging the battery

The battery charge indicator: your phone can monitor and display information about the battery.

Normally you can see the rest of the battery power from the battery power icon on the top right corner of the screen.

When the battery power is low, the screen will show "low power".

When the battery is being charged, it displays charging animation. When charging animation stops, it means charging is finished.

Power on/Off your phone

1. Press and hold the End key for 2 seconds to power on the phone.
2. When the phone is power on, press and hold the End key to power off the phone.

Function Menu

Phonebook

1. **View:** View the details for the selected record
2. **Send text message:** send text messages to the phone number
3. **Call:** Make a call to the phone number.
4. **Edit:** Edit the information of current number.
5. **Delete:** Delete the current record
6. **Add to Blacklist:** add the current number to the blacklist

7. Phonebook settings:

Memory status: Check the storage capacity of the SIM card and phonebook.

Copy contacts: Select SIM card into the phone SIM card copy records of all telephone numbers to cell phones or choose a mobile phone SIM card to a copy of the reverse operation.

Move contacts: Select SIM card into the phone SIM card records of all telephone numbers or choose to move to cell phone

Delete all contacts: options from the SIM card or from the phone to delete all.

Messaging

Write message: You may send SMS messages in this interface.

Inbox: You may read the received message in this interface. Unread message will show as unread message icon. Read message will show as read icon.

Click the options inside the Inbox interface:

View: check the received SMS

Reply: reply the sender via text message.

Call sender: using SIM1/SIM2 lines to call the sender back.

Forward: Forward the original message or modified message to others selected or inputted contacts.

Delete: deletes the current message.

Delete all: delete all messages in the inbox.

Call Center

Call history

1. Missed calls: You can view the missed call record in this interface.

2. Dialed calls: Display the dialed calls record.

3. Received Calls: Display the answered calls about the latest time and date, caller's number and calling times.

View: See the current record

Call: Call the current number.

Send text message: send text messages to the current record

Save to Phonebook: save the phone number to phonebook

Add to Blacklist: Add the current to the blacklist

Delete: choose to delete the current record

4. All calls: Display the all calls.

Call settings

Setup the current SIM card.

1.SIM1/SIM2 call settings: Call transfer and call waiting and other functions can be set in the menu.

Settings

Dual SIM settings

The user can refer to the SIM card usage to set the corresponding operation, this function in the double card insertion condition can choose:

Dual SIM open: open two SIM cards at the same time.

Only SIM1 card: open SIM1 card only.

Only SIM2 card: open SIM2 card only.

Phone settings

1. Time and date

In this interface, you can change the following setting:

1. **Set Home city:** Set the device Time Zone.
2. **Set Time/ Date:** Change the Time and date manually.
3. **Set format:** To change the display method of the Time and date.
4. **Auto Update Time:** To calibrate the time and date by network.

2. Language

You can choose different language as your requirement in this interface.

3. Pref. input method

To choose your commonly used input method as the default input method.

4. Display

Wallpaper: system provides 7 default images for wallpaper. You can also use your own image as the wallpaper by choosing the “User Defined”.

Screen auto lock: you can set the keyboard lock time according to your own needs.

Power on display: set boot animation

Power off display: set off animation

Show date and time: click open or close to said whether display date and time in standby.

5. Flight mode

In this interface, you could choose the flight mode and normal mode,

- If you choose Flight mode, all the network function will disable.
- The network function will restore after you choose the normal mode.

Network settings

You can change the network selection for each SIM card in this interface. To obtain the above network services, please contact your network operator.

Security settings

1. SIM1 (2) Security

You can setup or change the PIN code in this interface. Once you enable the PIN lock, it will restrict some phone function unless you input the correct PIN code to unlock it.

2. Phone securities

Using this function will lock your phone. A password is required to turn this function on or off. You will be asked to enter the password when you power on the device with SIM card.

Connectivity

1. BT

■ You can activate BT function in this menu, including start BT, search hands free device, my device, connectivity device, settings, my BT. Start BT, you can transfer the files to the matched BT and it can be paired with a BT headset to make a call.

Power: You can choose “activate” or “close” BT as your demand.

Visibility: Other BT devices cannot search your BT unless you enable this function.

My device: Used to search for new device or display already pairing successful device list record.

Search audio device: search audio device with BT function.

My name: display this phone’s BT name, and you can also modify it.

2 .Data connection SIM

Select SIM 1 or SIM 2 to connect to the network data.

3. Data accounts

Choose the service provider that you need to connect

Restore settings

This feature would reset parts of functions as those configured at the factory. The factory default password is 1122.

Audio player

Play: play the specified music..

Refresh list: Update the items of songs (updating shall be implemented after the name/names of song(s) are changed or some of the songs are deleted)

Settings: Set up relevant information of music player.

List auto gen: Setup for automatic updates

Repeat: you can specify shut, single music, all the way to a play

Shuffle: you can specify shut, single music, all the way to a play

Background play: If you choose the open state, exit the music player interface, music can still play. Otherwise, music will automatic stop to play.

Multimedia

Camera

Use the camera application, you can take picture for around people or events any time.

1. **Switch to video recorder:** Switch to video recorder from camera.
2. **Photos:** View the photos that you saved.
3. **Camera setting:** Set related parameters of the camera.
4. **Image settings:** Set the size and quality of the photos.
5. **Effect settings:** Set the special effects of photos.
6. **Storage:** Choose the position where the photos will be saved.
7. **Restore default:** Restore the camera settings to default.

Image viewer

You may view or modify photos saved in the album in this interface.

1. **View:** View the selected images.
2. **Send:** you can send the image by BT.
3. **Use as:** use the phone as wallpaper or power on/off display.

5. **Rename:** Rename the current picture.
6. **Delete:** Delete the picture.
7. **Storage:** Select to view in phone or memory.
8. **Image information:** Can be view the image information.

Video recorder

In the video interface, press up and down navigation keys to tune the focal length.

Note: Because the mobile memory capacity is limited, a T-flash card has to be inserted before you can save the video.

1. **Switch to camera:** Switch to camera from video recorder.
2. **Camcorder settings:** Set the related parameters for the video camera.
3. **Video settings:** Set related parameters for the video clip.
3. **Storage:** Select the position where video clips will be saved.
4. **Restore default:** Restore the video recorder settings to default.

Video player

Play user has recorded / downloaded video file, select a video according to the Options menu has the following functions:

1. **Play:** play a selected video file.
2. **Send:** send to other mobile by via BT.
3. **Rename:** change the file or folder name.
4. **Delete:** delete the file.
6. **Storage:** Choose video file storage path for mobile phones / T card.

Sound recorder

1. **New record:** Start recording.
 2. **List:** View the recording.
- Play:** Play a selected record.
- Rename:** Rename a selected record. Note: Renaming a record which has been set as incoming ring will make the settings back to defaults.
- Delete:** Delete a selected record.

Use as: Use the record as Ringtone and Message tone

Send: Send the record by BT.

3. Settings

Set the position and the file format to save records.

FM radio

This phone support the FM radio function.

Channel list: Set up the channel list and frequency.

Manual input: In put the frequency by manual.

Auto search: choose the “yes” then auto searching the channels.

Settings: Activate or inactivate the background and the speaker.

Record: Start recording

File list: View the recording.

Profiles

The Available profiles in your phone are: General, Silent, Meeting, Outdoor, and Headset.

You can edit the alert type, ring type, ring tones, ring volume, message tone, and message volume or set the button’s volume and voice call reminder according to your needs.

Note: the phone will automatically translate into headset mode after connecting the earphone; you can unplug the headset to return to former restored mode. In standby mode, a long press on “#” button automatically switches to meeting mode, press again to return to the normal model.

File Manager

Phone

You can use this function to manage the directories and files which are stored in the Micro SD card.

Open: Unfold a selected folder.

Format: Format the file system note: You'll lose all information in the file system.

Organizer

Calendar

To access the Calendar, press the left soft key. The first row displays year and month; the second row displays week; the middle part displays dates for a specific month; and the last row displays the two soft keys. In the calendar mode, view the previous week by pressing the up navigation key and the next week by pressing the down navigation key; View the previous day by pressing the left navigation key and the next day by pressing the right navigation key. The selected date is displayed in deep color.

Jump to date: Jump to the appointed date quickly when you input a date to search.

Go to today: See the other date, choose this, and can jump to today.

Alarm

You can set 5 alarms with this mobile. For each of them, you can set the alarm status to be open or not, set the alarm time and alarm frequency (once, daily or on several self-defined dates).

Flashlight

You can open and close the flashlight

Extras

Calculator

The cell phone support continuous four mixed arithmetic operation and the operation is simple, practical and convenient.

EBook reader

Reading. Txt format of the text of the document. May be a text document format through the USB data lines in mobile phone functionality to copy read.

Services

1. Internet service:

You can surf the internet, browse the relevant Web by WAP browser.

Safety Precaution

Not following these simple guidelines may be dangerous or illegal. Read the complete user guide for further information.

TURN ON SAFELY

Do not turn on the phone when wireless phone is prohibited or when it may cause interference or danger.

ROAD SAFETY

Obey all road safety laws. Always use both of your hands to operate the vehicle while driving.

INTERFERENCE

All wireless phones may be sensitive to interference, which may affect performance.

TURN OFF IN HOSPITALS

Follow all restrictions. Turn off the phone near medical equipment.

TURN OFF ON AIRCRAFTS

Follow all restrictions. Wireless devices can cause interference on aircrafts.

TURN OFF WHEN REFUELING

Do not use the phone at/near refueling stations. Do not use near fuel or chemicals.

USE SENSIBLY

Only qualified personnel may install or repair this product.

ENHANCEMENTS AND BATTERIES

Use only appropriate enhancements and batteries. Do not connect incompatible products.

BACKUP COPIES

Remember to make back-up copies or keep a written record of all important information stored in your phone.

CONNECTING TO OTHER DEVICES

When connecting to any external device, read its user guide for detailed safety instructions. Do not connect with incompatible products.

Other Warnings

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more

of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 1.0 cm from the body. Non-compliance with the above restrictions may result in violation of RF exposure guidelines.